



















3557G

MUST BE FITTED BY A PROFESSIONAL



1		WALL PLATE & FRONT PLATE	x1
2		ARMS FOR TV	x2
3		Extendable latch pull	x1
A		M5.3x40mm screw	x6
B		WALL PLUG	x6
C		SPIRIT LEVEL	x1
D		M6x20mm Cross round screw	x4
E		M8x16mm Cross round screw	x4
F		Φ6x16 washer	x4
G		Φ8 washer	x4
H		Φ6 plastic spacer	x4
I		4mm ALLEN KEY	x1
J		6mm ALLEN KEY	x1
K		M8x16mm Cross round screw	x4
L		Plastic cover 1	x4




3



5



4



MUST BE FITTED BY A PROFESSIONAL