
















# 3565G

# MUST BE FITTED BY A PROFESSIONAL

1		WALL PLATE & FRONT PLATE	x1	<b>1</b>	
2		ARMS FOR TV	x1		
3		ARMS FOR TV	x1		
4		Plastic cover	x2		
A		M6x55mm wall screw	x4	<b>2</b>	
B		WALL PLUG	x4		
C		M8x16mm screws	x4		
D		M6x20mm screws	x4		
E		Φ6 Plastic spacer	x4		
F		washer	x4		
G		6mm Allen key	x2		
H		M8x16mm screw	x4		
				<b>3</b>	

# MUST BE FITTED BY A PROFESSIONAL